

FENDER "BASSMAN" SCHEMATIC

MODEL 5E6-A

A-EE

NOTICE
VOLTAGES READ TO GROUND
WITH ELECTRONIC VOLT-
METER.
VALUES SHOWN +OR-20%

