

# FENDER "PRO-AMP" LAYOUT

## MODEL 5E5

### NOTICE

VOLTAGES READ TO GROUND  
WITH ELECTRONIC VOLTMETER.  
VALUES SHOWN + OR - 20%

